



- NOTES:
1. INSTALL MINIMUM 1" CONDUIT NIPPLE WITH WATER TIGHT FITTING
 2. FOR SINGLE PHASE APPLICATIONS, DELETE ONE CT AND BUSBAR SET
 3. FOR 120/240 & 120/208 VOLT DELETE VT'S AND VT ENCLOSURE



DULUTH, MINNESOTA

TRANSITION CABINET WITH SEPARATE ENCLOSURE FOR MOUNTING VT'S
120/240 & 120/208 & 277/480 VOLT
TYPICAL INSTALLATION